Chemo Mats / Spill Pads

Cobalt Blue[™] Chemo Prep Mats / Spill Pads, available in sterile and non-sterile are ideal for use in your cleanroom, barrier isolator, or glove box during HD compounding. These chemo mats will quickly and safely remove spills before they spread.

Features & Benefits

- · Absorbent, 3 ply material
- · Polyethylene and fiber blend
- · Validated Sterile and Non-Sterile Available
- Sterile option is validated to SAL (Sterility Assurance Level) of 10⁻⁶
- · Non-porous polyethylene backing
- · Ideal for ISO class 5 cleanrooms and higher
- Made in the USA

Sterile Chemo Mats

Product Name	Description	Size	Packaging
CBCM-1611.15	Gamma Irradiated, Lint Free, Highly Absorbent, Non-Porous Backing	16" x 11"	15 Mats/Bag, 10 Bags/Case
CBCM-2216.10	Gamma Irradiated, Lint Free, Highly Absorbent, Non-Porous Backing	22" x 16"	10 Mats/Bag, 20 Bags/Case

Non-Sterile Chemo Mats

Product Name	Description	Size	Packaging
CM-1611.50	Non-Sterile, Lint Free, Highly Absorbent, Non-Porous Backing	16" x 11"	50 Mats/Bag, 4 Bags/Case
CM-2216.50	Non-Sterile, Lint Free, Highly Absorbent, Non-Porous Backing	22" x 16"	50 Mats/Bag, 4 Bags/Case





860.265.2633 | high-techconversions.com

High-Tech Conversions, Inc. 1699 King Street, Enfield, CT, 06082

